



41 H Odell School Road  
Concord, NC 28027

(P): (704) 786-8158  
(F): (704) 788-6814

## **EXHAUST NEEDLE VALVE ASSEMBLY KIT, P/N 2000038, OPERATING INSTRUCTIONS**

### **Operating Instructions:**

- See Drawing Number 3000014 for part details.
- 1. To achieve maximum air exhaust flow, turn the needle valve knob fully counterclockwise to open the valve.
  - If knob is locked, pull the red lock ring out, away from the body of the valve, to unlock.
- 2. To lower flow rate, turn knob clockwise.
- 3. To stop the air flow completely, close the valve by turning the knob fully clockwise.

